19880916HI-DROPS

E.6 Omega Dropwindsonde Scientist (On-Board)

The on-board lead project scientist (LPS) on each aircraft is responsible for determining the distribution patterns for ODW releases. Predetermined desired data collection patterns are illustrated on the flight patterns. However, these patterns often are required to be altered because of clearance problems, etc. Operational procedures are contained in the operator's manual. The following list contains more general supplementary procedures to be followed. (Check off and initial.)

11101110		general supplementary procedures to be temented. (entent on and minum)						
6.1 P	refligh	ıt.						
1	1.	Determine the status of equipment and report results to the on-board LPS.						
_	2.	Confirm the mission and pattern selection from the LPS and assure that the proper number and distribution (frequency) of ODW's are on board the aircraft.						
_	3.	Complete the appropriate preflight calibrations and check lists.						
. Ir	n-Fligh	nt						
	1.	Operate the system as specified in the operator's manual.						
_	2.	Obtain drop release approval (for each drop) from the OAO flight director or navig for each specific time and location of drop.						
_	3.	Report to the LPS as soon as it is determined that the ODW is (or is not) transmitting a good signal.						
/	4.	Report completion of each drop and readiness for the next drop.						
_	5.	Complete Form E-6.						
P	ostflig	ht						
_	1.	Complete the summary form for ODW's.						
_	2.	Brief the on-board LPS on equipment status and turn in reports and completed forms to the LPS.						
_	3.	Hand-carry all ODW data tapes and printouts and inform the OAO flight director that you are arranging delivery as follows:						
,		 a. Outside of Miami - to the HRD operations center (FGOC). b. In Miami - to AOML/HRD (temporarily), either directly or via MGOC, for conversion to 9-track magnetic tapes. 						
_	4.	Debrief at the appropriate operations center (FGOC or MGOC).						
_	5.	Determine the status of future missions and notify the appropriate operations center (FGOC or MGOC) as to where you can be contacted.						

HRD Omega-Dropwindsonde Scientist Log

Page ____ of ___

Flight <u>880916H2</u>
Storm <u>GILBERT</u>

ODW Scientists BURPEE

RE

Operator JARYI

Drop #	Sonde ID #	GMT	Lat.	Long.	Wind (nats) (WD/WS)	Height (GA)	Temp. (TA)	Dew Pt. (TD)	Pressure (PS)	Remarks
1	24180	1852	23 58	978	320/1	1485	22.3	18.3	805.4	in the eye
2	21364	211	2858 24°06	97°30"	300/6	1493	21.6	18,9	805,6	in the eye
					,					9
			- 1							
		<u> </u>								
			10				,			
		274-17								

HRD Omega-Dropwindsonde Scientist Log

Page___ of ___

Flight	ODW Scientists
Storm	Operator

Drop #	Sonde ID #	Time GMT	Lat.	Long.	Wind (m/s) (WD/WS)	Height (GA)	Temp. (TA)	Dew Pt. (TD)	Pressure (PS)	Remarks
1000										
								77.0.4		
				9-19						