

## Boundary-Layer Scientist

The boundary-layer scientist (BLS) is responsible for data collection from AXBTs, AXCPs, AXCTDs, buoys, and SST radiometers (if these systems are used on the mission). General supplementary procedures follow. (Check off or initial.)

### Preflight

- \_\_\_\_\_ 1. Determine the status of equipment and report results to the Lead Project Scientist (LPS).
- \_\_\_\_\_ 2. Confirm mission and pattern selection from the LPS.
- \_\_\_\_\_ 3. Select the mode of operation for instruments after consultation with the LPS.
- \_\_\_\_\_ 4. Complete appropriate preflight check list.

### In-Flight

- \_\_\_\_\_ 1. Operate the instruments as directed by the LPS.

### Post flight

- \_\_\_\_\_ 1. Complete summary checklist and all other appropriate forms.
- \_\_\_\_\_ 2. Brief the LPS on equipment status and turn in completed checklists and any data tapes to the LPS.  
[Note: all data removed from the aircraft by HRD personnel should be cleared with the AOC flight director.]
- \_\_\_\_\_ 3. Debrief as necessary at base of operations.
- \_\_\_\_\_ 4. Determine the status of future missions and notify MGOc as to where you can be contacted.

AXBT and Sonobuoy Check Sheet (revised 6/23/04)

Flight Number 20170824A1 Storm Harvey Storm Direction/Speed \_\_\_\_\_

Drop #		Landing Time		Splash Time (HHMMSS)	SST AXBT	MLD (#secs x 1.5)	Comments
Drop #	Time (HHMMSS)	Lat Latitude (Decimal)	Lon Longitude (Decimal)				
1	040636	23° 51'	92° 43'				
2	050130	20° 28'	92° 28'				Back
3	053203	21° 18'	90° 54'				
4	0633	23° 56'	94° 10'		28°C		28°C
5	0702	21° 56'	94° 11'				
6	0805	24° 8'	90° 57'				